

Stor-DryTM_{MC}

LOW WATTAGE WARM AIR CIRCULATOR
CIRCULATEUR D'AIR CHAUD À FAIBLE CONSOMMATION ÉNERGÉTIQUE.

OPERATING INSTRUCTIONS
MODE D'EMPLOI

Uw Store Dry Dealer: www.Nauticgear.nl



9406CAABX - 120V AC, 60Hz



9406CA230EUABX - 230V AC, 50Hz

(Do not use with 220V AC, 60Hz)

(Ne pas utiliser avec 220v AC, 60Hz)

Stor-Dry™ Model 9406

SAVE THESE INSTRUCTIONS

The Stor-Dry Warm Air Circulator combats mold and mildew by reducing the amount of moisture available for spores to grow and multiply. This is accomplished using a unique dual action that utilizes both a low wattage heating element and a fan to circulate air.

Operating Instructions

Simply plug the unit into the appropriate outlet. Red LED indicates when unit is operating. Make sure that airflow is not restricted. The heater has been designed for continuous operation. Current draw is less than a 100 watt light bulb.

NOTE: The key to keeping any area free of moisture is proper ventilation.

CAUTION! Surface is hot, avoid contact.



WARNING:

This unit is equipped with a thermal protection device. Should the unit be covered in clothing or other material it may overheat and shut down. In the event of the unit overheating and shutting down, it will remain off until it is reset. To reset, unplug the unit and ensure that it is not covered by anything. Let the unit cool for ten minutes before plugging it back in.

Specifications

120 Volts, 60Hz, 0.6A, 70 Watts

230 Volts, 50Hz, 0.33A, 70Watts

Care and Maintenance


The Stor-Dry™ requires very little maintenance. By following the instructions within this manual the heater will operate problem-free for years.

Unplug unit before cleaning. A vacuum can be used to clear the heater of any dust build-up and a dry cloth may be used to wipe the outer surface.

Do not attempt to open the unit to clean.

Operation

An internal blower pulls cool, damp air in the bottom and releases warm dry air through the top. Active air circulation technology raises the ambient temperature above the dew point to control mold and mildew. Designed for low cost continuous use. The amount of water vapour air can hold (absolute humidity) increases with temperature. The Stor-Dry™ low wattage heating element slightly warms the room's air to keep the moisture suspended rather than condensing on surfaces where mold spores can use it to grow. Secondly, the Stor-Dry™ fan keeps a small amount of air moving throughout the room to help prevent any moisture from condensing on surfaces to again impede the growth of mold spores.



Important Instructions

When using electrical appliances, basic precautions should always be followed to reduce risk of fire, electric shock, and injury to persons including the following:

1. **SAVE THESE INSTRUCTIONS.**
2. Read all instructions before using the heater.
3. Use this heater on a horizontal and stable surface.
4. **WARNING:** Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
5. **CAUTION:** Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet from the front of the heater and away from the sides and rear.
6. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
7. Children shall not play with the appliance
8. Cleaning and user maintenance shall not be made by children without supervision.
9. Children of less than 3 years should be kept away unless continuously supervised.
10. Children aged from 3 to 8 years old shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 to 8 years of age shall not plug in, regulate or clean the appliance or perform user maintenance.
11. Always unplug heater when not in use.
12. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment or repair.
13. Do not use outdoors.
14. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
15. Do not run cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area and where it will not be tripped over.
16. To disconnect heater, remove plug from electrical outlet.
17. Connect heater to an appropriate electrical outlet which meets the electrical ratings as marked on the heater.
18. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage to the heater.
19. To prevent a possible fire, ensure air intakes and exhaust are free from obstructions. Do not use on soft surfaces, like a bed, where openings may become blocked.
20. Do not use it in areas where gasoline, paint or flammable liquids or materials are used or stored.
21. Do not use in areas where there is a risk of build-up of flammable materials.